

PART LIST OF VI/21.35

No.	Part No.	Description	PCS
1	51010	Air Spray Valve	1
2	90119	O-Ring	1
3	99006	Bolt	1
4	90120	O-Ring	1
5	91022	Bolt	4
6	51020	Top Cap	1
7	51030	Valve Bumper	1
8	51040	Gasket	1
9	51050	Cap Valve Spring	1
10	90121	O-Ring	1
11	90056	O-Ring	1
12	51060	Collar	1
13	51070	Cap Valve	1
14	90093	O-Ring	1
15	90094	O-Ring	1
16	90143	O-Ring	1
17	90049	O-Ring	1
18	63010	Piston Unit	1
19	90126	O-Ring	1
20	51081	Cylinder	1
21	22040	Bumper	1
22	91007-1	Bolt	2
23	91009	Bolt	2
24	91008	Bolt	1
25	12070	Guide Plate	1
26	98012	Bolt	1
27	63020	Nose	1
28	22090	Safety Cover	1

No.	Part No.	Description	PCS
29	12090-G	No Mar Tip	1
30	93003	Flat HD. Screw	3
31	93009	Flat HD. Screw	1
32	63070	Snib Cover	1
33	22280	Lock Out Spring	1
34	22290	Lock Out Pin	1
35	63040	Magazine Cover	1
36	58050	Plate	1
37	63030	Magazine	1
38	63060	Latch Bracket	1
39	98010	Screw	2
40	57060	Canopy	3
41	63050	Pusher	1
42	58100	Spring Pin	2
43	58120	Pusher Spring	2
44	98006	Screw	6
45	12170	Latch Spring	1
46	12160	Latch	1
47	12201	Magazine Cap	1
48	96010	Pin	1
49	92002	Washer	1
50	98020	Screw	1
51	51150	Trigger Pin	2
52	51160	Trigger	1
53	22370	Driver Guide	1
54	51214	Safety	1
55	90120	O-Ring	1
56	51180	Valve Guide	1

No.	Part No.	Description	PCS
57	51220	Trigger Valve Cover Spring	1
58	51190	Trigger Valve	1
59	90127	O-Ring	1
60	90128	O-Ring	1
61	51200	Trigger Valve Cover	1
62	51230	Trigger Valve Spring	1
63	97001	Nylon Nut	1
64	20180	Hook	1
65	51210	Hook Set	1
66	94006	Plug	1
67	51213	Silencer	1
68	91001	Bolt	2
69	91012	Bolt	1
70	95002	E-Ring	1
71	18390	Duble Trigger Latch Spring	1
72	51215	Double trigger	1
73	18370	Pin	1
74	95001	E-Ring	1
75	51171-1	Body	1
K1	51020-1	CAP ASS'Y	1
K2	51060-1	COLLAR ASS'Y	1
K3	51070-1	VALVE ASS'Y	1
K4	63010-1	PISTON RAM ASS'Y	1
K5	51081-1	CYLINDER ASS'Y	1
K6	63020-1	MAGAZINE UNIT	1
K7	51200-1	TRIGGER VALVE ASS'Y	1