



| No. | Code. | Description | unit | No. | Code. | Description | unit |
|-----|---------|-------------------|------|-----|----------|------------------------|------|
| 1 | 00.12 | O-Ring | 1 | 25 | 30.07.3 | Piston | 1 |
| 2 | 00.14 | O-Ring | 3 | 26 | 32.05 | Bumper | 1 |
| 3 | 00.26 | O-Ring | 1 | 27 | 39.00 | Exhaust gasket | 1 |
| 4 | 00.27 | O-Ring | 1 | 28 | 40.04.2 | Valve ass'y. | 1 |
| 5 | 00.35 | O-Ring | 2 | 29 | 45.04 | Ring | 1 |
| 6 | 01.21.1 | Gasket | 1 | 30 | 50.03 | Trigger Valve Assembly | 1 |
| 7 | 01.21.3 | Gasket | 1 | 31 | 72.03.3 | Support | 1 |
| 8 | 01.29 | O-Ring | 1 | 32 | 76.04 | Pin | 2 |
| 9 | 01.33 | O-Ring | 1 | 33 | 76.14 | Pin | 1 |
| 10 | 04.08 | Screw | 1 | 34 | 76.45 | Pin | 1 |
| 11 | 04.12 | Screw | 1 | 35 | 80.08 | Trigger | 1 |
| 12 | 04.16 | Screw | 2 | 36 | 81.09 | Trigger | 1 |
| 13 | 04.20 | Screw | 2 | 37 | 81.15 | Safety | 1 |
| 14 | 04.35 | Screw | 4 | 38 | 90.07 | Spring | 1 |
| 15 | 09.02 | Elastic Ring | 3 | 39 | 90.10 | Spring | 1 |
| 16 | 09.14 | Washer | 8 | 40 | 92.01X | Spring | 1 |
| 17 | 14.18.1 | Pin | 1 | 41 | 93.02 | Spring | 1 |
| 18 | 17.10 | Air Plug 1/4" | 1 | 42 | 22.00.81 | Driver | 1 |
| 19 | 20.00 | Body | 1 | 43 | 53.00.80 | Slider | 1 |
| 20 | 22.07 | Head | 1 | 44 | 62.00.81 | Magazine | 1 |
| 21 | 24.00 | Silencer | 1 | 45 | 70.00.81 | Pusher | 1 |
| 22 | 25.04.1 | Exhaust deflector | 1 | 46 | 81.00.80 | Nose | 1 |
| 23 | 26.07 | Cylinder | 1 | 47 | 91.01.81 | Nose Plate | 1 |
| 24 | 28.00 | Gasket | 1 | 48 | 00.70.5 | O-Ring Kit | 1 |